SEQUENCE FOR PUTTING ON MID LEVEL PPE with PAPR

Remove all personal items before starting (phones, jewelry, badges, etc.)

HAIR TIE/NET

Tie hair back into tight bun, use hair net if long hair

PAPR

- Turn on PAPR (hose will already be connected)
- Flow test hold hose at eye level and make sure flow meter is above both lines
- Buckle PAPR around waist and connect hose to the hood
- Place hood over head, pulling shroud around shoulders



Blue Gown

- Put on Blue Gown, fasten at back of neck
- complete coverage

Cover as much of hood and hose as possible Tie inside waist and outer waist to ensure

Gloves

- Put on pair of blue nitrile gloves
- Pull gloves over white cuffs of gown to ensure coverage





Use an Isolation Buddy to help you dress with the proper PPE



SEQUENCE FOR REMOVING MID LEVEL PPE with PAPR

GLOVES

Use Alcohol Based Hand Rub(ABHR) between each step

- Grasp outside of glove with opposite gloved hand; peel off
- Hold removed glove in gloved hand
- Slide fingers of ungloved hand under remaining glove at wrist
- Peel glove off over first glove
- Discard gloves in infectious waste bin, use ABHR



BLUE GOWN

- Untile both ties and undo the Velcro around the neck
- Grab clean inside part of gown, pull away from body
- Roll up gown place in infectious waste bin
- Use ABHR



PAPR HOOD

- Re-glove and grab a PDI Purple Top Wipe
- In mirror use PDI Purple Top Wipe to decontaminate: front, sides, back and top of hood for 2 minutes
- Remove gloves in same manner as the first step
- Place gloves into infectious waste bin
- Use ABHR





PAPR/PAPR HOOD

- Exit patient room into hallway
- Shut PAPR off and use ABHR
- Disconnect hood and hose, let hose hang down and use ABHR
- Grasp top of hood and slowly pull off away from body, place on cart; use ABHR
- Unbuckle PAPR and set on cart, use ABHR





FINAL STEP

 Grab another PID wipe and re-wipe down both PAPR and HOOD



ALWAYS USE HAND HYGIENE WHEN FINISHED