

SEQUENCE FOR **PUTTING ON** PERSONAL PROTECTIVE EQUIPMENT (PPE) with CAPR for High Level IDA

Remove all personal items before starting (phones, jewelry, badges, etc.)

HAIR TIE/NET

- Use ABHR (Alcohol based hand rub) on hands
- Tie hair back into tight bun, use hair net for long hair

GLOVES and TYVEK

- Put on pair of green long cuff gloves
- Step into white Tyvek and proceed to pull all the way up
- Push hole through cuff of Tyvek suit with thumb
- Put booties on, pull up all the way, attach strap

Battery Pack/Belt

- Place black wipeable belt around waist
- Obtain a fully charged battery
 - (LED should be green on charger)
- Attach battery to belt using clip

Cord, Shroud and Donning CAPR

- Put cage on CAPR. Attach foam comfort strip and shroud to helmet
 - Clear visor should face towards helmet
- Loosen adjustment knob so helmet easily fits over head
- Hold helmet in one hand and place CAPR over head
- Adjust knob to tighten around head
 - Pull shroud over head
 - Place extra filter over shroud
- Connect power cord to battery pack, listen for audible click of connection
 - 5 lights will illuminate
 - Green indicator should remain on
 - Amber indicator – unit needs inspected
 - Red indicator = battery 25% or less



Foam comfort strip

Blue Gown and Gloves

- Put on Blue Gown over shroud
- Partner will help tie and ensure complete coverage
- Put on pair of blue long cuff gloves over green gloves
 - Pull gloves completely over white cloth



Use Isolation Buddy to help you dress with Proper PPE
Check each other after every step to ensure complete coverage



SEQUENCE FOR **REMOVING** PERSONAL PROTECTIVE EQUIPMENT (PPE) with CAPR for High Level IDA

ALWAYS USE PROPER HAND HYGIENE WHILE REMOVING PPE

Outer Gloves/Bootstraps

- Proceed into ED hallway
 - Use ABHR, bend down undo bootstraps then use ABHR
 - Grasp outside of glove with opposite gloved hand; peel off
 - Hold removed glove in gloved hand
 - Slide fingers of clean green glove under blue glove at wrist
 - Peel second blue glove over first glove
 - Discard blue gloves in infectious waste bin, use ABHR
-

Blue Gown/Shroud

- Use Isolation Buddy to untie blue gown
 - Gown should be draped over shoulders
 - Grab clean inside part of gown, pull away from body
 - Roll up gown and place into infectious waste bin, use ABHR
 - Remove top filter from CAPR and place in infectious waste bin, use ABHR
 - Proceed to remove CAPR shroud, pull away from body
 - Place in infectious waste bin
 - Use ABHR on gloves
-

CAPR Battery, Belt, Helmet

- Push black button and disconnect cord from battery
- Leave battery on belt and place on Decon Cart
- Remove CAPR and place on Decon Cart
- Use ABHR



Tyvek and Booties

- Grab at the top of your shoulder, unzip and step out of Tyvek (including booties) onto clean portion of the floor
 - Reach over, ball up Tyvek/booties and place in infectious waste bin
 - Use AHBR on gloves
-

Inner Gloves

- Remove green gloves in same fashion as outer blue gloves, use ABHR
- Remove hair tie/net (if applicable)
- Wash hands with soap and water



Always use proper hand hygiene after each step

