#### 

# **Standard Operating Procedure**

Air handler motor maintenance will be performed in accordance with the manufacturer's recommendation and specifications.

### **Purpose**

To ensure proper air handler unit operation in all buildings.

### **Procedure**

## Annually:

- 1. Shut down air handler at motor control center.
- 2. Pull plugs on bottom of motor.
- 3. Purge old grease out and insert new grease.
- 4. Run a few minutes.
- 5. Shut down unit and put bottom plugs back.
- 6. Start up unit.