

Xerox® VersaLink® C500/C600 Family



Total width: 28 in (724 mm) **Total height:** 58 in (1,474 mm) **Total depth:** 30 in (772 mm)

Dimensions shown are approximate. Please refer to the Installation Guide for exact dimensions

VersaLink® C605 Multifunction Printer

Xerox® VersaLink® C605 Color Multifunction Printer,
Print/Copy/Scan/Email, Letter, Up To 55 ppm (53 ppm A4), 2-
Sided Print, USB/Ethernet, 550-Sheet Tray, 150-Sheet Multi-
Purpose Tray, 100-Sheet DADF (Single-Pass Duplex)



550 sheet tray

A 550-sheet sheet feeder for your Xerox® VersaLink® C500/C600 Color Printer and Xerox® VersaLink® C505/C605 Color Multifunction Printer is adjustable up to 8.5"x14" (legal) paper size.



High Capacity Feeder (HCF)

This 2,000-sheet high capacity sheet feeder for your Xerox® VersaLink® C500/C600 Color Printer and Xerox® VersaLink® C505/C605 Color Multifunction Printer is adjustable up to 8.5"x 14" (legal) paper size.



*HCF comes with a Caster Base

Finisher

The finisher/stapler for your Xerox® VersaLink® C600 Color Printer and Xerox® VersaLink® C605 Color Multifunction Printer can hold up to 500 sheets and staple up to 50 sheets at a time (single-position).



Fax

Adds Fax capabilities.

*Productivity Kit included when ordered with the VersaLink® C505 Multifunction Printer

PaperCut

PaperCut MF is a simple, low cost software application that lets you take control and manage your printers, copiers and multi-function devices. (May not be available in all countries)

Print and Scan for OneDrive

Print files from or scan documents to OneDrive. For print, the app includes support for Microsoft Office, PDF, Open Office, TIFF, JPEG, PNG, GIF, TXT, RTF, EML, XPS, PS and PCL. For scan, the app supports output formats of: PDF, PDF/A, XPS, TIFF and JPEG.

Once you have used the Product Explorer to configure your product, this QR code will allow you, or a sales person, to easily retrieve your configured product details.

How to use your QR Code

1. Open the QR Code reader on your phone, or download a QR code scanning app from your device's app store.
2. Hold your smartphone over the QR Code so that you can clearly see the image within your screen.
3. Your smartphone reads the code and navigates to the intended destination.



Created on 6/14/2019 3:13:16 PM

© 2019 Xerox Corporation. All rights reserved. Xerox®, Brenva®, ConnectKey®, iGen®, Iridesse®, Versant® and Xerox Nuvera® are trademarks of Xerox Corporation in the United States and/or other countries.